


COUNTING HEAD, CENTER PLATE – RIGHT SIDE (PHOTO / DIAGRAM # 11)



R1- Vacuum Switch (S-3043-1)	R10- Knife (S-6285-1)
R2- Tape Loading Lever (Ass'y – S-6045)	R11- Knife Linkage (S-6283)
R3- Looper Stop Switch (S-3105)	R12- Allen Screw
R4- Looper Driver Motor (S-3106-1)	R13- Nut
R5- Looper Drive Belt (S-6062)	R14- Tear Drop (S-6285-1)
R6- Knife Solenoid (S-3102)	R15 – Locking Nut (H-154)
R7 – Reset Reed Switch (S-3107)	R16 - Knife Adjusting Plate (S-6287)
R8- Tape On / Off Switch (S-3140)	R17 - Connecting Link Arm (S-6283)
** If equipped**	